

DE LOREAN MOTOR COMPANY

10804 Roark Road • Houston, Texas USA • (281) 568-9573 • (800) 872-3621 FAX (281) 568-9386 • www.usadmc.com • info@usadmc.com

1	Name						
Z DAIF	Address						
OWNER	Phone	Lic No	State	Repair No			
Š	Mileage	VIN	Interior	Transmission			
PFP	ARATION FOR WORK — □ Fit	fender cover seat ste	ering and floor covers M	lechanic			
	Observations and Modifications _						
itiai	Observations and Modifications_						
	Check speedo operation						
	Check for suspension and drivetrain noises or vibrations						
	Check operation of all instrumentation						
ES	Check vehicle performance						
=	Check for squeaks and rattles						
ROAD	Check for electric cool fans and A/C						
צ	Check for brake pedal pulse						
	Check steering column bushing						
				_			
	Check engine for: oil leaks, timing	g cover oil seal, timing	cover O ring, rear main s	seal			
	Check for original and leaks: oil filter, oil pressure switch, gauge, light						
	Check automatic transmission and final drive for fluid leaks						
	Check catalyst heatshield, muffler heatshield						
	Check for 90 amp alternator						
	Check exhaust manifold gaskets_						
J.	Check manual transmission for flu	uid leaks and linkage o	r bushing movement				
S	Check engine/transmission (mour	its and brackets)					
7	Check steering suspension - chec	k play/leaks, inspect ste	eering column universal jo	oints and rack boots			
UNDERSIDE	Check drive shafts - Inspect boots	- Check play/leaks					
	Check shock absorbers						
	Check brake circuit - check leaks	, check condition of fle	exible hoses				
	Check brake pads/discs - check wear/condition						
	Brake disc minimum thickness	- 11.5mm LF	RF LR	RR			
	Brake calipers						
	Master cylinder seals, pistons a	nd complete units					
				"Underside" continued ⇒			

Owr	ners Name VIN Page 2
	Check grease ball joints
	Fuel lines - check condition leaks
	Clutch - check hydraulic circuit for leaks
	Check for installation of stainless steel clutch line
(pg	Check front and rear ground connections
nue	Check front and rear wheel bearings
(continued)	Check front end recall performed
	Check frame for rust
DERSIDE	Check crumple tube
ERS	Check air deflector plates
Z	Check frame for any sings of collision damage
U	Check for seat belt anchor plugs
	Check radiator (original or replacement)
	Check operation of louvre latch and struts
	Check engine cover latch and support
	Check engine cover grilles, mounts and decals
	Check driving belts and A/C belt idler bearings
	Check valve covers for leaks
	Cooling system - Pressure test, check leaks
	Inspect hoses: left and right, main hose, configuration early/late
ENJ	Check automatic transmission level
TM	Exhaust system - check leaks/chafing, inspect muffler brackets
AR	Fuel system - check leaks.chafing, perform fuel system pressure and rest test primary control
ME	Air conditioning - check compressor
\mathcal{C}^{C}	Check mounting bolts
INE	Check pipe condition/leaks
ENGINE COMPARTMENT	Check refrigerant level
	Accelerator Cable - check for full throttle opening
	Check air filter and duct hoses
	Check de-ice recall installation
	Check header bottle
	Check torque on rear body mounts
	Check engine compartment light and switch

wn	vners ivame VIIV VIIV Page 3				
	Tires -	Check pressure			
S AND TIRES		Check cuts/damage on inside/outside walls			
		Check tires comply to manufacturer's specifications			
		Check wheel alignment			
	Wheels -				
		Check for correct valve stems			
		Check for condition of wheel emblem caps			
ΜM					
	·	o up brake and clutch reservoir			
⊢		ndition of hood seal and carpet			
MEN.		ndshield washer reservoir level			
₹TI		ndition of windshield wiper blades			
PA		que on front body mounts			
COMPART		ol kit for completeness			
		are tire condition and pressure			
AG		fuel pump update and condition of rubber boot and cover			
UGGAGE	Check flex	xible fuel lines			
ľΩ	Check op	eration of trunk light and trunk struts			
	Chock ho	adlamps: main/dipped beam			
		adlamp flasher operation			
CAR		verse lamps operationrking/side lamps operation			
	·	ar number plates lights operation			
SID		p lights operation			
Ž					
ND		dicators/hazard warning lights operation			
LAI		erior light			
ICA		rns operation			
ELECTRICAL AND INSIDE		ndshield operation			
		ndshield washer			
		ectric windows operation and for new style regulators wipe seals			
		eration of band brakes			
	спеск ор	eration of hand brakes			

Own	ers Name	VIN	Page 4
	Check hood release cable for fraying at end		
	Clean all fuse contacts		
	Check for relay update installation		
	Check electric mirror operation and condition of mirrors		
ed)	Check electric door lock operation and escutcheon condition	1	
inu	Check mode control switch for operation and for vacuum lea	ıks	
(continued)	Check blower motor operation and for noises		
	Check condition of seats and soft trim		
CAR	Check operation of electric radio antenna if applicable		
DE	Check pedal pads for wear		
INSIDE	Check brake and clutch pedal linkage pivot pins for wear		
	Check clutch master cylinder for leaks		
AND	Check headliners		
:AL	Check binnacle and dash		
CTRICAL	Check door panels for cuts or wear		
ECT	Check for armrest extensions and protectors		
Н	Check radio cassette operation and speakers		
	Check battery type, size and condition		
	Check front and rear fascia for paint damage		
	Check all door seals and silicone seal on door seals		
	Check operation of door locks early/late style		
	Check operation of door struts		
	Check operation of door lights		
	Check condition and security of body moldings		
	Check condition of headlights and exterior lenses and screws	S	
TERIOR			
IER			
EX.	Check condition of stainless body work		
			_